Rumble Blaster

USER'S GUIDE

for Wii™

The Rumble Blaster is designed for use on the Nintendo Wii. It is compatible with all light gun, target style and 1st person shooters. It features rumble & dual triggers that will enhance your gaming experience.

dreamGEAR®
www.dreamgear.net

BOX CONTENTS:
Rumble Blaster (can be separated into 2 parts)
User Guide
Warranty Card

SET-UP (Wii Remote)
1. Lift up the front and rear bars of the Rumble Blaster remote casing.
2. Place your Wii Remote into the Rumble Blaster casing with the top of the Wii Remote going in first.
3. Snap bottom of Wii Remote into Rumble Blaster casing.
4. Press down on both bars until they click.

SET-UP (Wii Nunchuck)
1. Place Nunchuk into the back of casing sliding up top first.
Note: The bottom of the Nunchuk should snap into place when secured.
2. Wrap Nunchuk cable along the thin handle and into the bottom hole of the middle part of the casing.
3. Lift up top blue cover.
4. Wrap cable around the 2 hooks starting with the bottom hook. (You should be able to wrap the cable around each hook twice.)
5. Pull the excess of the cable through the top slit of the Nunchuk casing.
6. Replace the top blue cover.

SET-UP (Attaching Rumble Blaster)
1. Lift up the blue bar at the bottom of the Wii Remote gun casing.
2. Take the end of the Nunchuk cable that is sticking out of the top of the Nunchuk casing and slide it through the blue bar at the bottom of the Wii Remote gun casing.
3. Plug in the end of the Nunchuk cable into the Wii Remote.
4. Press down on the blue bar at the bottom of the Wii Remote gun casing until it clicks.
5. Attach the Wii Remote gun casing and the Nunchuk casing by sliding the end of the Nunchuck casing over the end of the Wii Remote gun casing. (It should snap into place.)

TO DETACH CASINGS TO FORM TWO (2) SEPARATE UNITS:
1. Slide the Nunchuk casing upward from the Wii Remote gun casing to separate.
2. Lift up the blue bar at the bottom of the Wii Remote gun casing.
3. Unplug the Nunchuk cable from Wii Remote.
4. Press down on the blue bar at the bottom of the Wii Remote gun casing until it clicks.

FOR RUMBLE FEATURE:
1. Detach the battery cover on the back of the handle of the Wii Remote gun casing.
2. Place two (2) “AAA” batteries into battery slot.
3. Replace cover.
Note: Rumble feature will be activated by pressing on either trigger button on the Wii Remote gun casing.

TROUBLESHOOTING:

Problem: The Rumble Blaster will not vibrate when triggers are pressed.
Solution: Make sure that you use fresh batteries and the batteries are inserted properly and securely. Replace batteries.

Problem: The triggers do not activate the A and B buttons on the Wii Remote.
Solution: Make sure that the blue bars are closed properly. They should be pressed down until you hear a click to confirm that they have been closed properly.

Problem: The Nunchuk doesn’t work.
Solution: Make sure that the end of the Nunchuk cable is attached properly and securely to the bottom of the Wii Remote.
how to info goes here.

dreamGEAR®
www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net